

FIG. 1




FIG. 1A




FIG. 2




FIG. 3

410

Manual Editor: Acquire Dimension Information

Width of the rectangle:

40cm

412

Height of the rectangle:

4.5cm

414

416

Save

418

Cancel

405

425

Manual Editor: Acquire Position Information

Position of the rectangle:

(210, 335)

426

Angle of the rectangle:

75 degrees

427

428

Save

429

Cancel

420

FIG. 4A




FIG. 4B




FIG. 5

FIG. 6A is a schematic diagram of a manual editor interface for refining dimension information. The interface is divided into two main sections: a top section for refining dimension information (610) and a bottom section for refining position information (630). The top section (610) contains two input fields: "Width Adjustment:" (612) with a value of "1.5cm" and "Height Adjustment:" (614) with a value of "0.5cm". The bottom section (630) contains two input fields: "Position Adjustment:" (632) with a value of "(2,4)" and "Angle Adjustment:" (634) with a value of "3.0 degrees". Both sections have "Save" (617, 637) and "Cancel" (618, 638) buttons. The interface is titled "Manual Editor: Refine Dimension Information" (610) and "Manual Editor: Refine Position Information" (630).

610

Manual Editor: Refine Dimension Information

Width Adjustment :

1.5cm

612

Height Adjustment:

0.5cm

614

617

Save

618

Cancel

605

630

Manual Editor: Refine Position Information

Position Adjustment:

(2,4)

632

Angle Adjustment:

3.0 degrees

634

637

Save

638


Cancel

620

FIG. 6A

600





650

FIG. 6B




FIG. 7




FIG. 8




FIG. 9

# 1000




FIG. 10

1100




FIG. 11

1200




FIG. 12